

EasyTech.One is a Pellet stoves control system available in Air and Idro version.

Is characterised by:

- Installing and use simplicity
- Simple and direct user's functions
- Reliable and flexible functioning software with well-established TiEmme elettronica technology
- Advanced functions available for the builder to adapt to different stoves and installations

Product composition:

- Control Board with 4 fixing points, solid and sure.
- Extractable connectors
- Exhausting Temperature Probe until 500 °C
- Room Temperature Probe
- Connection cable Main Board - Control Panel
- Control Panel with antistatic cover
- Connector RS232 for the Modem/Computer connection

Safety rules

Before working on the system make follow:

- The accident prevention and Room prevention rules
- The National Institute rules against the work accidents
- The legal safety rules
- These instructions are only for technical personnel only



Conformity declaration

Applied rules: EN 60730-1 50081-1 EN 60730-1 A1 50081-2


This manual is done with care and attention, but the information could be incomplete, not comprehensive or could have mistakes. For this reason the design, the information could be modified without advance notice according to the model.

TiEmme elettronica is not responsible for the incomplete or not correct information

TiEmme elettronica 06055 Marsciano (PG) Italy

Tel.+39.075.874.3905; Fax. +39.075.874.2239 info@tiemmeelettronica.it

1 ELECTRICAL CONNECTIONS




| PIN | | Funzione | Caratteristiche |
|------|--------|-----------------------------------|---|
| 1 | N | Voltage Power Supply | 230 Vac ± 10% 50/60 Hz F1 = Fuse T5,0 A |
| 2 | L | | |
| 3 | N | Combustion Fan | Triac Regulation 1A max |
| 4 | L | | |
| 5 | N | Heating Fan | Triac Regulation 1A max |
| 6 | L | | |
| 7 | N | Igniter Resistance | Relè 3 A max |
| 8 | L | | |
| 9 | N | Auger Pellet Engine | Triac Regulation 1A max |
| 10 | L | | |
| 11 | | Safety Thermostat Input HV1 | Contact ON/OFF Normally closed To Bypass if not used |
| 12 | | | |
| 13 | | Safety Pressureswitch Input HV2 | Contact ON/OFF Normally closed To Bypass if not used |
| 14 | | | |
| 15 | Red+ | Exhausting Temperature Probe | Thermocouple K: 500 °C Max |
| 16 | Green- | | |
| 17 | | Room Temperature Probe | NTC 10K @25 °C: 120 °C Max |
| 18 | | | |
| 19 | | AUX Temperature Probe | Not used |
| 20 | | | |
| 21 | +5V | Encoder Signal | Signal TTL 0 / 5 V |
| 22 | GND | | |
| 23 | SEG | | |
| 24 | | AUX Input: Chrono/Room Thermostat | Contact ON/OFF |
| 25 | | | |
| 28 | GND | Level Pellet Sensor | Signal 0 / 5 V |
| 29 | SEG | | |
| 31 | +V | | |
| CN1 | | Connector for Control Panel | Flat Cable |
| RS23 | | Connector RS232 | Connection to Modem/Computer |

2 CONTROL PANEL: USE AND FUNCTIONS

2.1 LED

| Led | Fix | Blinking |
|-----------|------------------------|--------------------------|
| L1 | Stabilization phase | Ignition Start phase |
| L3 | Stove OFF | Extinguishing phase |
| L4 | Work phase | Modulation/Standby phase |
| L5 | Engine Auger ON | |
| L6 | Igniter Resistance ON | |
| L7 | Chrono Program enabled | |
| L8 | Heating Fan ON | |



2.2 DISPLAY

| Display | Fix | Blinking |
|-----------|---------------------------|-------------------------|
| D1 | Time | |
| D2 | Work Combustion Power set | Combustion power change |
| D3 | Room Thermostat set | Room Thermostat change |

2.3 BUTTONS


| Tasto | Click [P click] | Long Pressure [P long] |
|-----------|--------------------------|-------------------------------------|
| P1 | Display other data | Ignition/Extinguishing /Block Reset |
| P2 | Combustion Power Setting | Manual Pellet Loading |
| P3 | Thermostat Setting (+) | Pellet Loading Correction |
| P4 | Thermostat Setting (-) | Combustion Fan Speed Correction |

| 2.4 ALARMS | | |
|--|-----------|---------|
| DESCRIPTION | | Display |
| Safety Thermostat HV1: signalled also in case of Stove OFF | Block ALT | Er 01 |
| Safety PressureSwitch HV2: signalled with Combustion Fan ON | Block ALT | Er 02 |
| Extinguishing for Exhausting Temperature lowering | Block ALT | Er 03 |
| Extinguishing for Exhausting over Temperature | Block ALT | Er 05 |
| Encoder Error: No Encoder Signal (in case of P25=1 or 2) | Block ALT | Er 07 |
| Encoder Error: Combustion Fan regulation failed (in case of P25=1 or 2) | Block ALT | Er 08 |
| Failed Ignition | Block ALT | Er 12 |
| Lack of Voltage Supply | Block ALT | Er 15 |
| Lack of Fuel | Block ALT | Er 18 |
| DAY and TIME not correct due to prolonged absence of power supply | Block ALT | Er 11 |
| Anomaly in probe control during Check Up phase | | 50nd |
| The reset of the BLOCK Condition is done by the Long Pressure of the button P1 | | |

3 USER'S MENU (1)


3.1 IGNITION/EXSTINGUISHING

The Ignition is activated with a long pushing of the button **P1**
 The Ignition is signalled by the first blinking than fix led **L1**
 The Work state is signalled by the fix led **L4**
 The Modulation state is signalled by the blinking **L4**
 The Extinguishing is activated with a long pressure of the button **P1**
 The Extinguishing is signalled by the blinking led **L3**
 The Extinguishing finished =OFF state is signalled by the fix led **L3**




3.2 COMBUSTION POWER SETTING

Click button **P2**: the display **D2** blinks
 With other click of the button **P2** the power is changed according to the values
 Ex.: **1 - 2 - 3 - 4 - 5 - A** (**A**= Automatic Combustion)
 After 3 seconds the new value is memorised and the display shows as normal




3.3 WORK THERMOSTAT SETTING

Click button **P3** or **P4**: the display **D3** blinks
 With other click of the buttons **P3 / P4** the value of the thermostat is increased or decreased
 After 3 seconds the new value is memorised and the display shows as normal




3.4 MANUAL PELLET LOADING

The long pressure of button **P2** activates the Pellet Manual Loading with activation of Auger engine in continuous way. The bottom display shows the actual function
 The up display shows the passed loading time
 To stop the loading push any button
 The loading stops automatically after 300 seconds




3.5 PELLET LOADING CORRECTION

The long pressure of button **P2** activates the Pellet Manual Loading with activation of Auger engine in continuous way. The bottom display shows the actual function
 The up display shows the passed loading time
 To stop the loading push any button
 The loading stops automatically after 300 seconds



3.6 COMBUSTION FAN SPEED CORRECTION

The activation is with a long pushing of the button **P2**
 The bottom display shows **UEnt**
 The Display **D1** shows the blinking value
 With buttons **P3 / P4** the blinking value increases or decreases
 The values are between the range $-7 \div 7$. The default value is '0'
 After 3 seconds the new value is memorised and the display shows as normal



3.7 DISPLAY


Whith click of **P1**.

tA = Room Temperature

tF = Exhausting Temperature

UF= Combustion Fan Speed
[RPM/Volt]]

A 02=Product Code



3.8 RADIO REMOTE CONTROL

The button **1** activates the Extinguishing ; the button **2** activates the Ignition

The buttons **3 / 4** decrease / increase the Power Combustion


Code Change:

On the Remote Control:

- Open the battery box moving right the cover
- Modify dip-switch's configuration and close the box

On the Thermoregulator:

- Switch OFF the power supply (230 Vac)
- Switch ON the Power Supply pressing at the same time one button on the Remote Control waiting about 5 seconds until an acoustic signal is emitted confirming the code learned



4 USER'S MENU (2)

Push contemporary the buttons **P2** and **P4** for three seconds to enter into User Menu (2)

- To scroll the Menu push the buttons **P3** or **P4**
- To enter in a submenu push the button **P2**
- To modify the blinking value push the button **P3** (to increase) or **P4** (to decrease)
- To exit push the button **P1**

4.1 CHRONO

It allows to programme and enable the ignitions/extinguishing

4.1.1 ENABLE

It enables the Programming set.

Push the button **P2** to enter

Push the buttons **P3/P4** for select

ON= enable programming set **OFF**=disable programming set

To confirm, push the button **P2**, or push **P1** to esc

Cr On

En Ab

4.1.2 PROGRAM

It allows to schedule the 3 time bands available for every day of the week

Select *P r O G*

Push the button **P2** to enter

Use the buttons **P3/P4** to visualize the time bands set:

- The upper display visualizes the TIME SET
- - - - if the BAND is disabled
- The bottom display visualizes: DAY / BAND / ON/OFF
- The long pressure of the button **P1** Enables / Disables the selected time band

- - - - 20.30
BAND DISABLED TIME SET

BAND OFF
3. TU 3. TU
ON DAY BAND DAY

PROGRAM CHRONO ACROSS MIDNIGHT

- Set the time **ON** for the previous day to the wanted value: Example 20.30
 - Set the time **OFF** for the previous day at: **23:59**
 - Set the time **ON** for the next day at **00:00**
 - Set the time **OFF** for the next day to the wanted value: Example 6:30
- The system will turn ON on Tuesday at 20.30, and will turn OFF on Wednesday at 6.30

20.30

3. TU

6.30

1. UE

4.2 TIME AND DATE

It allows to set the current day and time

DATE

4.3 RADIO REMOTE CONTROL

It enables the Radio Remote Control

Push the button **P2** to enter

Push the buttons **P3/P4** for select

On= Enabled **OFF=Disabled**

To confirm, push the button **P2**, or push **P1** to esc

LELE

5 INSTALLER'S MENU

TPAR

Push contemporary the buttons P2 and P4 to enter into the menu, protected by Password

5.1 AUGER MENU

TPO1

Setting of the **Auger TimeON** defined for each phase/power in the **Auger Period P05**

If the set value is = **0** the Auger is disabled to the relative phase/power

If the set value is \geq **P05** the Auger works continuously for the relative phase/power.

It's possible to set the TimeON of the Auger with steps of 0.1 seconds.

The setted or calculated values are automatically delimited between the thresholds **P05** and **P27**

| Code | Description | Min | Max | U | Def. |
|------------|---|------------|-----------|-----|------|
| C01 | Auger TimeON Ignition | 0 | 60 | [s] | |
| C02 | Auger TimeON Stabilization | 0 | 60 | [s] | |
| C03 | Auger TimeON Power 1 | P27 | 60 | [s] | |
| C04 | Auger TimeON Power 2 | P27 | 60 | [s] | |
| C05 | Auger TimeON Power 3 | P27 | 60 | [s] | |
| C06 | Auger TimeON Power 4 | P27 | 60 | [s] | |
| C07 | Auger TimeON Power 5 | P27 | 60 | [s] | |
| C08 | Auger TimeON during Periodic Cleaning | 0 | 60 | [s] | |
| C10 | Auger TimeON Second Ignition | 0 | 60 | [s] | |
| C11 | Auger TimeONn Modulation | P27 | 60 | [s] | |
| P05 | Total Time Auger Period | 4 | 60 | [s] | |
| P15 | Correction Step value of the value Auger TimeON | 1 | 20 | [%] | |
| P27 | Minimum Auger TimeON | 0 | 60 | [s] | |

5.2 COMBUSTION FAN MENU

TPO2

Setting of the Combustion fan speed for each power/phase of functioning

P25=1: Encoder version > values are in RPM; **P25=0: No Encoder version** > values are in Volt

> The set or calculated values are automatically delimited between the thresholds **P14** and **P30**

| Code | Description | Min | Max | U | Def. |
|------------|---|---|-------------|------|------|
| U01 | Ignition Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U02 | Stabilization Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U03 | Power 1 Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U04 | Power 2 Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U05 | Power 3 Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U06 | Power 4 Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U07 | Power 5 Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U08 | Speed during the Periodic Cleaning | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U09 | Speed during the Extinguishing | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U10 | Second Ignition Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| U11 | Modulation Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| P14 | Combustion Fan Minimum Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| P30 | Combustion Fan Maximum Speed | 0 | 230 | Volt | |
| | | 300 | 2800 | RPM | |
| P16 | Correction Step Value of the Combustion Fan Speed | 1 | 20 | [%] | |
| P25 | 0 | Combustion Fan no Encoder | | | |
| | 1 | Combustion Fan with Encoder | | | |
| | 2 | Combustion Fan with Encoder with automatic passage to P25=0 in case of not Signal Encoder: alarm Er07 | | | |
| | | 0 | 2 | [nr] | |

5.3 HEATING FAN MENU

TPO3

Setting of the heating fan speed for each power of functioning

| Code | Description | Min | Max | U | Def. |
|------------|---|-----|-----|------|------|
| F01 | Power 1 Speed | 0 | 230 | Volt | |
| F02 | Power 2 Speed | 0 | 230 | Volt | |
| F03 | Power 3 Speed | 0 | 230 | Volt | |
| F04 | Power 4 Speed | 0 | 230 | Volt | |
| F05 | Power 5 Speed | 0 | 230 | Volt | |
| P06 | 1 Heating Power = Combustion Power | 1 | 2 | [nr] | |
| | 2 Heating Power Automatic with Exhausting Temperature | | | | |

5.4 THERMOSTAT'S MENU

TPO4

Setting of the system's functioning thermostats

| Code | Description | Sonda | Min | Max | U | Def. |
|-------------|---|------------|-----|-----|------|------|
| Th01 | Stove OFF Thermostat | Exhausting | 5 | 900 | [°C] | |
| Th02 | Igniter Resistance disable Thermostat | Exhausting | 5 | 900 | [°C] | |
| Th03 | Pre-Extinguishing Thermostat for not Flame | Exhausting | 5 | 900 | [°C] | |
| Th05 | Heating Fan enable Thermostat | Exhausting | 5 | 900 | [°C] | |
| Th06 | Thermostat to go in Stabilization from Variable phase | Exhausting | 5 | 900 | [°C] | |
| Th07 | Modulation Thermostat for Exhausting OverTemperature | Exhausting | 5 | 900 | [°C] | |
| Th08 | Safety Thermostat for Exhausting OverTemperature | Exhausting | 5 | 900 | [°C] | |
| Th09 | Ignition Bypass Thermostat | Exhausting | 5 | 900 | [°C] | |
| Th28 | Stove OFF Thermostat in Standby | Exhausting | 5 | 900 | [°C] | |
| Ih33 | Room Thermostat Hysteresis | Room | 0 | 10 | [°C] | |
| d01 | Increasing Delta Temperature in Stabilization | Exhausting | 0 | 100 | [°C] | |
| d04 | Delta Exhausting Temperature for Heating fan Automatic Regulation [P06=2] | Exhausting | 1 | 50 | [°C] | |
| d05 | Delta Room Temperature for Combustion Power Automatic Regulation [A] | Room | 3 | 30 | [°C] | |
| d23 | Increasing Delta Room Temperature over the Room Thermostat to go from Modulation to Standby, if A01=2 , at the end of T43 | Room | 0 | 50 | [°C] | |

5.5 TIMER MENU

TPO5

Setting of the system's functioning phases

| Code | Description | Min | Max | U | Def. |
|------------|--|-----|------|-------|------|
| T01 | Ignition: Cleaning Time | 0 | 900 | [s] | |
| T02 | Ignition: Igniter Resistance Pre-heating Time | 0 | 900 | [s] | |
| T03 | Ignition: Pre-load Time | 0 | 900 | [s] | |
| T04 | Ignition: Fix Time | 1 | 3600 | [s] | |
| T05 | Ignition: Variable Time | 1 | 3600 | [s] | |
| T06 | Ignition: Stabilization Time | 0 | 900 | [s] | |
| T07 | Interval Periodic Cleaning Repetition | 15 | 600 | [min] | |
| T08 | Periodic time Cleaning | 0 | 900 | [s] | |
| T09 | Delay time HV1 Safety intervention | 1 | 900 | [s] | |
| T10 | Delay time HV2 Safety intervention (PressureSwitch) | 1 | 900 | [s] | |
| T11 | Delay time for Standby Exit | 0 | 900 | [s] | |
| T13 | Minimum Period Time of Extinguishing | 0 | 900 | [s] | |
| T14 | Waiting time Pre-Extinguishing for no flame | 0 | 900 | [s] | |
| T15 | Waiting time Pre-Extinguishing in Safety | 0 | 900 | [s] | |
| T16 | Final Cleaning Time | 0 | 900 | [s] | |
| T17 | Delay time Combustion Power Change | 0 | 900 | [s] | |
| T18 | Delay time Combustion Power Change in exit from Ignition | 0 | 900 | [s] | |
| T22 | Delay time for Standby Input | 0 | 900 | [s] | |
| T24 | Signal duration of Fuel's lack | 0 | 3600 | [s] | |
| T43 | Time, after which the stove goes from Modulation to Standby if Room Temperature > [Room Thermostat t+ d23] and A01= 2 | 0 | 9600 | [s] | |

5.6 ENABLE'S MENU

TP08

Setting of the system's general functions

| Code | Description | Min | Max | U | Def. |
|------------|---|--|----------|----------|------|
| A01 | 0 | Reached the Room Thermostat the stove goes in Extinguishing | | | |
| | 1 | Reached the Room Thermostat the stove goes in Modulation | | | |
| | 2 | Reached the Room Thermostat, the stove goes in Modulation, then if d23 satisfied and after T43 goes in Standby | | | |
| A06 | 0 | In Modulation the system uses Power 1: C03,U03 | | | |
| | 1 | In Modulation the system uses Modulation Power: C11,U11 | | | |
| A07 | 0 | The input AUX is used for ON/OFF functioning | | | |
| | 1 | The input AUX is used for Modulation/Normal functioning | | | |
| | 2 | The input AUX is used for Standby/Normal functioning | | | |
| A26 | 0 | The immediate Exit from StandBy is allowed | | | |
| | 1 | Exit from Standby is allowed >after the timer T13 and >if the Exhausting Temperature < Th28 | | | |
| A28 | 0 | Auger brake not enabled | | | |
| | 1 | Auger brake enabled | | | |
| A50 | 0 | Modem Management disabled | | | |
| | 1 | Modem Management enabled | | | |
| P02 | Maximum number ignition attempts | | 1 | 5 | [nr] |
| P03 | Work Combustion Powers' number | | 1 | 5 | [nr] |
| P09 | Sensor Level Pellet Setting: 0 =sensor input N.C. ; 1 =sensor input N.O. | | 0 | 1 | [nr] |

5.7 OUTPUTS MENU TEST

TP12

It allows the test the management of single outputs with the connected devices.
The function is available in **OFF** state.

| Code | Description | Min | Max | U | Def. |
|---|-------------------------|------------|-------------|--------|------|
| To01 | Engine Auger Test | Off | On | - | |
| To02 | Heating Fan Test | 0 | 230 | [Volt] | |
| To03 | Combustion Fan Test | 0 | 230 | [Volt] | |
| | | 300 | 2800 | [RPM] | |
| During the Combustion Fan Test, the upper display shows the set value [Volt o [RPM], the under display shows the number per rounds of the fan detected by the encoder if is present: in this way it is possible to create a conversion table [RPM] / [Volt] to use for the passage from encoder Mode P25=1 to not encoder Mode P25=0 in case of encoder breakage | | | | | |
| To04 | Igniter Resistance Test | Off | On | | |

5.8 MENU EXTINGUISHING THERMOSTATS

TP13

Settings for each Combustion Phase/Power of the Exhausting Temperature under which, after the Pre-Extinguishing time **T14**, the stove goes in Extinguishing for no flame.

These values occur with the Th03 Thermostat

| Code | Description | Probe | Min | Max | U | Def. |
|-------------|-------------------------|------------|----------|------------|------|------|
| Th35 | Power 1 | Exhausting | 5 | 900 | [°C] | |
| Th36 | Power 2 | Exhausting | 5 | 900 | [°C] | |
| Th37 | Power 3 | Exhausting | 5 | 900 | [°C] | |
| Th38 | Power 4 | Exhausting | 5 | 900 | [°C] | |
| Th39 | Power 5 | Exhausting | 5 | 900 | [°C] | |
| Th40 | Phase Periodic Cleaning | Exhausting | 5 | 900 | [°C] | |
| Th43 | Modulation Power | Exhausting | 5 | 900 | [°C] | |

6 FUNCTIONING STATES

| 6.1 OFF | | | | | |
|---|--------------------------------------|---|---|---|---|
| Timer | Controls | | Combustion Fan | Auger | Igniter |
| | If Exhausting Temp. > Th01 | → goes in Extinguishing | OFF | OFF | OFF |
| 6.2 CHECK UP | | | | | |
| Timer | Controls | | Combustion Fan | Auger | Igniter |
| T01 | If Exhausting Temp. > Th09 | → goes in Normal | Max Speed | OFF | OFF |
| 6.3 PRE-HEATING | | | | | |
| Timer | Controls | | Combustion Fan | Auger | Igniter |
| T02 | If Exhausting Temp. > Th09 | → goes in Normal | U01 | OFF | ON |
| 6.4 PRE-LOADING | | | | | |
| Timer | Controls | | Combustion Fan | Auger | Igniter |
| T03 | If Exhausting Temp. > Th09 | → goes in Normal | U01 | ON | ON |
| 6.5 FIXED PHASE | | | | | |
| Timer | Controls | | Combustion Fan | Auger | Igniter |
| T04 | If Exhausting Temp. > Th09 | → goes in Normal | U01 | C01 | ON |
| 6.6 VARIABLE PHASE | | | | | |
| Timer | Controls | | Combustion Fan | Auger | Igniter |
| T05 | If Exhausting Temp > Th09 | → goes in Normal | I Ignition: U01 II Ignition: U10 | I Ignition: C01 II Ignition: C10 | ON If Exhausting Temp. < Th02 |
| | If Exhausting Temp > Th06 | → goes in Stabilization | | | |
| Control after T05 | If Exhausting Temp < Th06 | → tries again Ignition from 5.6 Variable phase → goes in Extinguishing with error E12 in case of finished number of attempts | | | |
| 6.7 STABILIZATION | | | | | |
| Timer | Controls | | Combustion Fan | Auger | Igniter |
| T06 | If Exhausting Temp > Th09 | → goes in Normal | U02 | C02 | ON If Exhausting Temp. < Th02 |
| | If Exhausting Temp < Th06 | → Tries again Ignition from 5.6 Variable phase | | | |
| → goes in Extinguishing phase with error E12 in case of finished number of attempts | | | | | |
| Control after T06 | If Exhausting Temp > Th06+d01 | → goes in Normal → Tries again Ignition from 5.6 Variable phase → goes in Extinguishing phase with error E12 in case of finished number of attempts | | | |

6.8 RECOVER IGNITION

The system goes in **Recover Ignition**:

- After a lack Voltage Supply when the stove were in **ON**, when the voltage return if the Exhausting Temperature > **Th06+D01**
- Pushing the button ON/OFF when the system is in **Extinguishing**

| Timer | Controls | | Combustion Fan | Auger | Igniter |
|--|----------------------------------|---|---------------------|------------|------------|
| T16 Control after T16 | If Exhausting Temp > Th01 | → waits and continues extinguishing | U09 | OFF | OFF |
| | If Exhausting Temp < Th01 | → starts Timer T16 of final cleaning | Velocità Max | | |
| | If Exhausting Temp < Th01 | → goes in Check Up | | | |

6.9 NORMAL

| Parameters | Controls | | Combustion Fan | Auger | Igniter |
|--|--|--|---------------------|---------------------|------------|
| T14 Control after T14 | If Exhausting Temp < Thermostat Th03 or If Exhausting Temp < Extinguishing Thermostat for the used power | → starts Timer T14 of pre-extinguishing waiting | User's Power | User's Power | OFF |
| | → Goes in Extinguishing with error Er03 | | | | |
| | If Exhausting Temp > Thermostat Th07 | → goes in Modulation | | | |
| A01=1 o 2 | If Room Temperature > Room Thermostat | → goes in Modulation | | | |
| A07=1 | If Input AUX open | | | | |
| A07=2 | If Input AUX open | → goes in Standby | | | |
| T15 Control after t15 | If Exhausting Temp > Thermostat Th08 | → starts Timer T15 | | | |
| | → Goes in Extinguishing phase for Security | | | | |

6.10 MODULATION

| Parameters | Controls | | Combustion Fan | | Auger | | Igniter |
|--|--|--|----------------|--------------|--------------|--------------|------------|
| T14 Control after T14 | If Exhausting Temp. < Thermostat Th03 or If Exhausting Temp. < Extinguishing Thermostat for the used power | → starts Timer T14 of pre-extinguishing waiting | A06=1 | A06=0 | A06=1 | A06=0 | OFF |
| | Goes in Extinguishing phase with error Er03 | | U11 | U03 | C11 | C03 | |
| T15 Control after t15 | If Exhausting Temp. > Thermostat Th08 | →starts Timer T15 | | | | | |
| | → Starts Extinguishing with error Er05 | | | | | | |
| A01=2 | If for time T43 the Room Temperature > Room Thermostat +d23 | → goes in Standby | | | | | |

| 6.11 STANDBY | | | | | |
|---|---|---------------------------|------------------|------------|------------|
| Parameters | Controls | | Combustion Fan | Auger | Igniter |
| T13 Extinguishing Control after T13 | If Exhausting Temp > Thermostat Th28 | → starts Timer T13 | U09 | OFF | OFF |
| | If Exhausting Temp > Thermostat Th28 | → wait | | | |
| T16 Final Cleaning Control after T16 | If Exhausting Temp < Thermostat Th28 | → starts T16 | Max Speed | | |
| | → Goes in Standby OFF | | OFF | | |

| 6.12 EXTINGUISHING | | | | | |
|---|---|---------------------------|------------------|------------|------------|
| Parameters | Controls | | Combustion Fan | Auger | Igniter |
| T13 Extinguishing Control after T13 | If Exhausting Temp > Thermostat Th01 | → starts Timer T13 | U09 | OFF | OFF |
| | If Exhausting Temp > Thermostat Th01 | → wait | | | |
| T16 Pulizia Finale Control after T16 | If Exhausting Temp < Thermostat Th01 | → starts Timer T16 | Max Speed | | |
| | → Goes in OFF without errors | | OFF | | |
| → Goes in Block with possible errors | | | | | |



| 6.13 BLOCK | | | | |
|-------------------------------|-------------------------------------|----------------|------------|------------|
| Controls | | Combustion Fan | Auger | Igniter |
| To exit: | Push for 3 seconds button P1 | OFF | OFF | OFF |
| With no more block conditions | → Goes in OFF | | | |

7 FUNCTIONS

7.1 MODEM MANAGEMENT

The system manages a modem module (given on demand) for the dialogue with the stove through SMS to operate the Ignition, Extinguishing, State's request and have information about the Block/Alarms conditions. The Modem is connected to the Control Board's port RS232 with cables and connectors given; it is supplied with a AC/DC Power Supply unit.

- Use a SIM card in the Modem enabled to the traffic GSM data
- Disable the PIN request from the SIM
- The Modem management is activated with the parameter **A50 = 1**
- The insertion and removal of the SIM card **MUST** be done with the Modem **NOT** supplied



The user can send an SMS to the Modem's SIM with a command word:

| | |
|---------------|---|
| Start | To start Ignition from stove OFF. The Modem sends back a message to the number from which it received the command with a status and a possible alarm error code. |
| Stop | To start Extinguishing from stove ON. The Modem sends back a message to the number from which it received the command with a status and a possible alarm error code. |
| Status | To ask the stove's State . The Modem sends back a message to the number from which it received the command with a status and a possible alarm error code. |
| Learn | To Learn the number to send an SMS in case of Block. If there is a Block condition, the Modem automatically sends a message to the learnt number with the stove's state and the alarm error code. |

The key words can be written both capital and small.

7.2 SUPPLY VOLTAGE LACK MANAGEMENT

In case of Supply Voltage lack, the system saves the most important functioning data. With the return of the Supply Voltage, the system evaluates the saved data and:

- If the stove were ON and the Exhausting Temperature more than **Th06+d01** the system goes in **Recover Ignition**. Pushing the button P1 it is possible the sudden new system's Ignition.
- If the stove were ON but the Exhausting Temperature is less than **Th06+d01** the system goes in **Extinguishing** with error **Er15**.
 - If the stove were OFF, or in Extinguishing or Block, the system returns in the previous state.

7.3 COMBUSTION POWER CHANGE DELAY MANAGEMENT

When the system exits from the Ignition and goes in **Normal**, the Combustion Power, starting from the Combustion Power 1, reaches the target one increasing the value with the delay time as the timer **T18**.

The other manual or automatic power changes are managed and actuated with the delay time as timer **T17**.

7.4 BRAZIER'S PERIODIC CLEANING

When the stove is activated, the system automatically starts the brazier's periodic clearing.
With intervals as Timer **T07** (minutes) the Combustion is taken to Periodic Cleaning Power according to parameters **C08** and **U08** for the Timer **T08** (seconds).

7.5 AUTOMATIC COMBUSTION POWER MANAGEMENT

In the Combustion Power setting [par. 3.2], the user can set the Automatic modality [A]
The work power is automatically selected according to the Room Temperature and the value of the selected Room Thermostat:

- Room Temperature \leq **Room Thermostat-d05**
→ The system goes to the maximum available Combustion Power
- **Room Thermostat-d05** < Room Temperature < **Room Thermostat**
→ The Combustion Power decreases reaching the Room Thermostat
- **Room** Temperature \geq **Room Thermostat**
→ The system goes to Combustion Power 1 if **A06=0** or to Modulation Power if **A06=1**

| | | | | | | | |
|------------------------------|----------------|-----------------------|-----------|-----------|--------------------------------|-----------------------------|----------------|
| Example: | A06 = 1 | Modality = [A] | | | Room Thermostat = 25 °C | d05 = 5 °C | P03 = 5 |
| Room Temperature °C | < 20 | 21 | 22 | 23 | 24 | ≥ 25 | |
| Work Combustion Power | Power5 | Power4 | Power3 | Power2 | Power1 | Power1 | |

7.6 HEATING POWER MANAGEMENT

The Heating Fan works as follows:

- Is ON only if Exhausting Temperature is more than Thermostat **Th05**
- In Modulation or Standby for Room Thermostat it goes to Power 1
- In Modulation for Exhausting Temperature (Exhausting Temperature > **Th07**) goes to Maximum Power
 - During all the Ignition phase goes to Power 1

The parameter **P06** sets the heating power management according to modalities:

- **P06=1** The Heating Power is the same of Combustion Power
- **P06=2** The Heating Power is automatically selected by the system according to the Exhausting Temperature, the value of the Thermostat **Th05** and the parameter **d04**

| | | | | | | |
|----------------------------------|----------------|---------------------|--------------------|----------------|------------------|------------------------------|
| Esempio: | P06=2 | Th05 = 60 °C | d04 = 10 °C | P03 = 5 | | |
| Exhausting Temperature °C | < 70 | 70 ÷ 79 | 80 ÷ 89 | 90 ÷ 99 | 100 ÷ 109 | ≥ 110 |
| Heating Power | OFF | Power1 | Power2 | Power3 | Power4 | Power5 |

7.7 PELLET LOAD CORRECTION MANAGEMENT

The user could correct with procedure in Par. 3.5 the Auger's times ON of Pellet Loading in Step - 7 ÷ 7
P15 is the percentage value of the single correction Step and is applied on the Work default values.

| | | | | | | | |
|----------------|------------------|----------------|----------------|----------------|----------------|----------------|----------------|
| Example | P15=10% | C03=2,0 | C04=3,0 | C05=4,0 | C06=5,0 | C07=6,0 | C11=1,0 |
| | Step= --1 | C03=1,8 | C04=2,7 | C05=3,6 | C06=4,5 | C07=5,4 | C11=0,9 |

The defined values are within the defined range **P27 ÷ P05**

7.8 COMBUSTION FAN CORRECTION MANAGEMENT

The user could correct with procedure in Par. 3.6 the Combustion Fan Speed in Step - 7 ÷ 7
P16 is the percentage value of the single changing Step and is applied on the Work default values.

| | | | | | | | |
|----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Example | P16=5% | U03=1000 | U04=1200 | U05=1400 | U06=1600 | U07=1800 | U11=900 |
| | Step= +3 | U03=1150 | U04=1380 | U05=1610 | U06=1840 | U07=2070 | U11=1035 |

The defined values are within the defined range **P14 ÷ P30**

7.9 SPEED COMBUSTION FAN MANAGEMENT

The parameter **P25** sets the regulation modality of the Exhausting Fan Speed

| | |
|--------------|--|
| P25=0 | Exhausting Fan without Encoder: the speed is defined by the set voltage value [Volt]. The Regulation Step is of 5 Volt. |
| P25=1 | Exhausting Fan with Encoder: the speed is defined by the set number of turns [RPM] In case of signal presence but regulation failed, the system goes in BLOCK with Er08 alarm In case of sensor break with absence of the signal, the system goes in BLOCK with Er07 alarm |
| P25=2 | Exhausting Fan with Encoder: the speed is defined by the set number of turns [RPM] In case of signal presence but regulation failed, the system goes in BLOCK with Er08 alarm In case of sensor break with absence of the signal, the system goes in BLOCK with Er07 alarm. After the reset of the BLOCK done by the button P1 , the system goes Automatically to P25=0 |